

Uninstall Guide


BL-565 Bluetooth CF+ Card in Windows2000

Version: 1.0




Uninstallation Guide for BL-565 Bluetooth Compact Flash Card in Windows 2000


Open Windows "Control Panel"




Double Click "Add/Remove Hardware"




Click Next




Select "Uninstall/Unplug a device", then click "Next"




Select "Uninstall a device" then Click "Next"




Select the device you wish to uninstall



Please Note: Do NOT choose any of the Brain Boxes Bluetooth Layers listed




Confirm you have made the correct selection by Selecting "Yes, I want to uninstall this device and click "Next"




Click "Next"




Wait for the next screen to complete automatically




Confirm device Uninstall by dicking “Next”




Let the next screen complete automatically



Click Finish



Click "Finish"



In some instances the uninstall program may not have been able to remove certain files as they are still in use by the operating system. In this case, before trying to re-install any Brain Boxes Bluetooth software you are advised to re-boot your PC.

Version History

Version	Date	Author	Checked By	Comments
1.0	13/05/2002	Gavin Jewell		Using Beta4